

X6200 Assembly Guide ADDENDUM

IMPORTANT NOTES:

In **STEP 3 (PINK BAG)**, the hardware bag now has six M8x20L bolts instead of six M8x15L bolts.

In **STEP 6 (BLACK BAG)**, the hardware bag should reflect the information below. As a result of this hardware change, the first bullet point should state: **On the right side, slide the dual-action axle cover into place on the console mast axle. Slide the right dual-action arm on the axle. Slide washer (8.2x18x1T), cap and washer (8.3x28.5x2T) onto the bolt (M8x13L), and then put them onto the axle.**

